



MX PrimeGen

Power Generator

305939 Rev0

SERVICE AND MAINTENANCE MANUAL

TABLE OF CONTENTS

| | | |
|-----------|--|-----------|
| 1 | COPYRIGHT, LIABILITY, AND CONTACT INFORMATION | 1 |
| 2 | IMPORTANT SAFETY INSTRUCTIONS..... | 2 |
| 2.1 | MANUAL ICONS AND SAFETY BANNERS..... | 4 |
| 2.2 | TECHNICALLY QUALIFIED PERSONNEL..... | 4 |
| 2.3 | BATTERY SAFETY | 4 |
| 2.4 | START-STOP OPERATIONS | 5 |
| 3 | DATA PLATE..... | 6 |
| 4 | RECOMMENDED MAINTENANCE INTERVALS | 7 |
| 5 | RECOMMENDED PARTS FOR SERVICE..... | 8 |
| 6 | TOOLS REQUIRED FOR SERVICE | 10 |
| 7 | ARRIVAL ON-SITE | 11 |
| 8 | AIR SYSTEM | 13 |
| 9 | BATTERY SYSTEM..... | 15 |
| 9.1 | BATTERY INSPECTION | 15 |
| 9.2 | BATTERY REPLACEMENT..... | 16 |
| 10 | OIL SYSTEM | 17 |
| 11 | COOLANT SYSTEM | 19 |
| 11.1 | CHANGING COOLANT | 20 |
| 11.2 | REPLACING COOLANT PUMP | 23 |
| 11.3 | SERVICING THE THERMOSTATIC VALVE | 24 |
| 11.4 | TOPPING UP THE RADIATOR FLUID | 24 |
| 12 | ELECTRICAL SYSTEM..... | 26 |
| 12.1 | CUSTOMER TERMINATIONS | 26 |
| 12.2 | SENSOR LOCATIONS..... | 27 |
| 12.3 | CURRENT PROTECTION..... | 30 |
| 12.4 | THERMAL FUSE LOCATIONS..... | 32 |
| 12.5 | CHECKING ELECTRICAL CONNECTIONS..... | 33 |
| 13 | CHECKING AND ADJUSTING VALVE CLEARANCES..... | 34 |
| 14 | CYLINDER COMPRESSION TEST..... | 37 |
| 15 | IGNITION SYSTEM | 39 |
| 15.1 | SPARK PLUG REPLACEMENT | 39 |
| 15.2 | SPARK PLUG WIRE REPLACEMENT | 39 |
| 15.3 | CHANGE IGNITION COILS..... | 39 |
| 16 | VALVE CLEANER TREATMENT | 40 |
| 17 | REPLACING O₂ SENSOR | 41 |
| 18 | ZERO GOVERNOR TROUBLESHOOTING..... | 42 |

| | | |
|-----------|---|-----------|
| 19 | MAINTENANCE HOURS RESET | 43 |
| 20 | MX PRIMEGEN SITE INSTALLATION & COMMISSIONING REPORT | 44 |
| 21 | MX GENERATOR MAINTENANCE LOG | 46 |

TABLE OF FIGURES

| | |
|--|----|
| Figure 3-1 – Data Plate | 6 |
| Figure 3-2 – MX Model Tree..... | 6 |
| Figure 8-1 – Engine Air Intake Standard (left) & Cold Ambient (right) configuration..... | 13 |
| Figure 8-2 – Engine Air Circulation | 13 |
| Figure 8-3 – Enclosure Intake Duct Screen | 14 |
| Figure 8-4 – Engine Filters..... | 14 |
| Figure 9-1 – MX Batteries..... | 15 |
| Figure 9-2 – MX Battery Clamp | 16 |
| Figure 10-1 – Long Run Oil Configuration | 17 |
| Figure 10-2 – MX Lower Panel Grommet..... | 17 |
| Figure 10-3 – Oil Reservoir | 18 |
| Figure 11-1 – Radiator Assembly | 19 |
| Figure 11-2 – Upper Petcock Location | 20 |
| Figure 11-3 – Engine Block Petcock Location | 21 |
| Figure 11-4 – PLC HMI | 22 |
| Figure 11-5 – Filled radiator | 22 |
| Figure 11-6 – Coolant pump installation..... | 23 |
| Figure 11-7 – Thermostatic Valve Parts | 24 |
| Figure 11-8 – Coolant Reservoir | 25 |
| Figure 12-1 – Customer Wiring Terminations (3 Phase & Single-Phase Systems)..... | 26 |
| Figure 12-2 – MX Sensor Locations Front Panel..... | 28 |
| Figure 12-3 – MX Sensor Locations Back Panel..... | 28 |
| Figure 12-4 – MX Sensor Locations Side Panel..... | 29 |
| Figure 12-5 – MX Sensor Locations Electrical Cabinet | 29 |
| Figure 12-6 – Location of Circuit Breakers, Fuses, J9/J11 Modules, and Spare Fuse Holder | 31 |
| Figure 12-7 – Layout and Fuse Numbers of DC Power Module J9 and Fuse Module J11..... | 32 |
| Figure 12-8 – #13 Thermal Fuse (Electrical Room) | 32 |
| Figure 12-9 – #14 Thermal Fuse (Engine Room) | 33 |
| Figure 13-1 – Pulley & Engine Block Marking Alignment..... | 34 |
| Figure 13-2 – Rocker Arm & Valve Stem | 34 |
| Figure 13-3 – Pulley & Engine Block Marking Alignment..... | 35 |
| Figure 13-4 – Rocker Arm & Valve Stem | 36 |
| Figure 14-1 – Jumper Wire Placement..... | 37 |
| Figure 15-1 – MX Ignition System | 39 |
| Figure 16-1 – Air Intake Elbow Location | 40 |
| Figure 17-1 – O ₂ Sensor Location | 41 |
| Figure 18-1 – Zero Governor Location and Plug Location..... | 42 |

TABLES

| | |
|---|----|
| Table 1 - Maintenance Schedule | 7 |
| Table 2 - Maintenance Materials | 8 |
| Table 3 - Customer Wiring Connections (3 Phase & Single-Phase Systems)..... | 26 |
| Table 4 - List of Sensors..... | 27 |

| | |
|--|----|
| Table 5 - Circuit Breaker and Fuse Protection List | 30 |
| Table 6 - Cylinder Compression Test Reference Table..... | 38 |

1 COPYRIGHT, LIABILITY, AND CONTACT INFORMATION

This manual provides instructions for the installation, operation, performance, basic maintenance and troubleshooting of the MX Power Generators built after April 2026. Please see the old service manual 303453 and manual 302672 if your unit was built before this date. In the event of unforeseen or special problems, do not take unauthorized remedial action. Contact GPT's Customer Service department to obtain the necessary information. All agreements, assurances, and legal relationships as well as all obligations of GPT, shall be governed by the respective valid purchase contract which is not influenced by the content of this document. For any technical issues or questions:

Global Power Technologies – Head Office

#16, 7875 – 57 Street SE

Calgary, Alberta

Canada T2C 5K7

Phone: 1-403-236-5556

Fax: 1-403-236-5575

Customer Service/Technical Support: 1-403-720-1190

Copyright

Copyright © 2026 by Global Power Technologies (GPT). All rights reserved. No part of this manual may be reproduced without permission in writing from GPT, except by a reviewer who may quote brief passages or reproduce illustrations in a review with appropriate credit; nor may any part of this manual be reproduced, stored in a retrieval system, or transmitted in any form or by any means – electronic, photocopying, recording, or otherwise – without prior permission in writing from GPT.

Liability

The user is expressly warned to consider and adopt all safety precautions that might be indicated by the activities herein and to avoid all potential hazards. The user assumes all risks in connection with such instructions. GPT shall not be liable for any special, consequential, exemplary, or other damages resulting, in whole or part, from the user's use of, or reliance upon this material.

Comments

GPT has compiled this publication with care, but GPT does not warrant that the information in this publication is free of errors. Comments, criticisms, and suggestions regarding the subject matter are invited. Any errors or omissions in the data should be brought to the attention of GPT. If required, affected pages will be revised and issued.

2 IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS – This manual contains important instructions for the MX PrimeGen Power Generator that should be followed during installation and maintenance of the generator and its batteries. Read the following safety warnings before beginning assembly, installation, or maintenance of the MX Power Generator.

1. Observe all prescribed accident prevention and safety rules. Do not perform work on the MX Power Generator alone—make sure there is somebody else working with you.
2. The installation of the MX Power Generator must conform with local codes or, in the absence of local codes, with CSA-B149.1 – Natural Gas and Propane Installation Code.
3. When installed, the MX Power Generator must be electrically grounded in accordance with local codes, or in the absence of local codes, with CSA C22.1 – Canadian Electrical Code.
4. The MX Power Generator is not intended to be used in underground mines. Do not use the MX system in underground mines.
5. The MX Power Generator and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures more than 34 kPa (5 psi).
6. The MX Power Generator must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 34 kPa (5 psi).
7. Do not use the MX Power Generator if any part has been under water. Immediately call a qualified service technician to inspect and to replace any part of the control system, gas control and generator that has been under water.
8. The MX Power Generator is designed to combust gaseous fuels which will result in combustion products of heat, carbon dioxide and water vapor. It may contain traces of carbon monoxide, unburnt hydrocarbons, and nitrous oxides. Emissions from combustion will depend on generator set-up and operation as well as the composition of the gas feed. It is imperative that these instructions be followed, and that gas supplied meets the gas specifications outlined in this manual.
9. The MX Power Generator must be mechanically installed according to the instructions contained within this manual. It must be securely anchored to a non-combustible surface when installed.
10. Installation and repair must be performed by a qualified service person. The MX Power Generator should be inspected before use and at least annually by a qualified service person. More frequent cleaning may be required as necessary. It is imperative that control compartment, air intakes, and circulating air passageways of the system are kept clean.
11. The MX Power Generator uses an internal combustion engine. Qualified service personnel should have mechanical knowledge on how to maintain engine fuel, lubrication, ignition, and cooling systems.
12. The MX Power Generator contains electrical and gas-related safety devices as identified throughout this manual. Tampering or rendering inoperative any of these safety devices may result in personal injury or death and possible damage to the equipment and is not permitted under any circumstances.
13. The MX Power Generator has some parts constructed from sheet metal. Every effort is made to ensure that edges have been deburred when manufactured, however sharp edges may still exist. Be cautious when handling. Wear gloves for safety.

14. Any guard or other protective device removed for servicing from the MX Power Generator must be re-installed prior to operating the system.
15. The MX contains sub-systems that combust gaseous fuel and others that run high electrical loads, all of which can pose high surface temperature hazards. Avoid exterior areas, as well as internal components of the generator to avoid burns or clothing ignition when in operation or cooling down.
16. The MX Power Generator contains rotating parts, hot surface temperatures, and high voltages. It also has remote start and stop capabilities. Do not begin work on the MX Power Generator unless it is shut-off manually, switched to LOC mode, and locked out so that the system cannot be started remotely or inadvertently. Follow the shutdown procedure in the MX Manual (305876).
17. The MX Power Generator uses natural gas or propane as fuel. In the event of a leak, there is a possibility of a fire and explosion. To help avoid leaks, perform leak checks as recommended in this manual.
18. Lethal voltages are present in this system. The MX Power Generator has either 120/240 VAC systems or 120/208 VAC as well as 24 VDC systems. Use accepted safety procedures for working on all electrical circuits. Follow all local electrical safety regulations.
19. Study the MX Power Generator wiring diagrams and schematics before working on electrical circuits and ensure that all tools used while working on electrical circuits are insulated.
20. The MX Power Generator contains batteries. Avoid touching live battery terminals and placing tools on or near the batteries. These can provide dangerous voltages and currents, even when the system is shut-off.
21. As soon as electrical cabinet doors are opened or terminal covers are removed, there is the danger of contacting hazardous voltages. Any operations inside the cabinets or with exposed electrical terminals must only be carried out by qualified electrical personnel. If in doubt, do not touch.
22. Sparking and arcing may occur if a wire is connected or disconnected with a heavy current flow. Arcing can burn skin or eyes and damage equipment. Before making electrical connections ensure all breakers are open and wires are not energized.
23. The MX Power Generator includes spark plug electrode, which needs to be accessed during maintenance. Do not touch the conductor of a spark igniter electrode while it is energized.
24. The MX Power Generator is not intended for use as emergency power.
25. Keep the MX Power Generator's installation site clear and free from combustible materials, gasoline, and other flammable vapours and liquids. Maintain the minimum clearances specified in this manual.
26. Fuel supplied to the MX Power Generator must not contain liquids. Liquid hydrocarbons in the fuel supply pose a risk of fire and may result in serious damage and danger to the operator.
27. Do not exceed the fuel pressure stamped on the MX Power Generator's data plate without factory approval.
28. The MX Power Generator exhaust can be very hot. Do not touch any of the exhaust components or bring exposed skin near hot exhaust gases.
29. When the MX Power Generator is operating, surface temperatures of the exhaust can approach temperatures above 70°C (158°F). Avoid contact of skin and clothing with the surfaces of the exhaust to avoid burns. The MX unit must be installed so that the risk of contact by people is minimized.

30. The MX Power Generator is designed FOR OUTDOOR USE ONLY.

2.1 MANUAL ICONS AND SAFETY BANNERS



A banner with the word “WARNING!” below an icon with an exclamation point within a red triangle contain important information that, if not adhered to, can cause personal injury and/or property damage.



A banner with the word “CAUTION!” below an icon with an exclamation point within a red triangle contain important information that, if not adhered to, can cause damage to the MX Power Generator.

NOTE:

A banner with the word “NOTE:” contains supplemental information that provide additional insight on specific topics throughout this manual.

2.2 TECHNICALLY QUALIFIED PERSONNEL

This manual contains necessary information for the correct operation of the MX Power Generator and is intended for use by technically qualified service personnel. Qualified personnel are persons who are:

- ✓ Familiar with the erection, installation, commissioning, and operation of the device and of the system which is being installed or in which the device is being installed.
- ✓ Capable of performing switching operations according to safety technology standards and are authorized to switch the equipment on and off and to isolate it from voltage.
- ✓ Have mechanical knowledge on how to maintain engine fuel, lubrication, ignition, and cooling systems.
- ✓ Trained according to local safety standards, wear proper personal protective equipment (PPE), and trained in immediate rescue measures (first aid).
- ✓ Completed instructions with appropriate confirmation by an appropriately qualified instructor.

2.3 BATTERY SAFETY

1. Servicing of batteries are to be performed or supervised by personnel knowledgeable of batteries and the required precautions. Keep unauthorized personnel away from batteries.
 2. When replacing batteries, use the same quantity and the following type batteries: Type 31 AGM batteries, 12V, 100-105 Ah.
-



Do not dispose of battery or batteries in a fire. The battery is capable of exploding.



Do not open or mutilate the battery or batteries. Released electrolyte has been known to be harmful to the skin and eyes and to be toxic.



A battery presents a risk of electrical shock and high short circuit current.

WARNING!

3. The following precautions are to be observed when working on batteries:
 - Remove watches, rings, or other metal objects.
 - Use tools with insulated handles.
 - Wear rubber gloves and boots.
 - Do not lay tools or metal parts on top of batteries.
 - Disconnect charging source prior to connecting or disconnecting battery terminals.
 - Determine if the battery is inadvertently grounded. When inadvertently grounded, remove source of ground. Contact with any part of a grounded battery is capable of resulting in electrical shock. The risk of such shock is reduced when such grounds are removed during installation and maintenance (applicable to a generator not having a grounded supply circuit).

2.4 START-STOP OPERATIONS

1. The MX Power Generator is equipped with an Emergency Shutdown (ESD) button that acts as the absolute emergency shutdown of the system. Operators must shut down the device prior to doing any maintenance or repair on the system.
2. A manual shut-off valve must be installed according to local standards at the fuel inlet to allow fuel supply to be cut off in the event of any problems. Refer to the MX Installation and Operation Manual (305876) for details.

3 DATA PLATE




| | | | | | |
|---|--------------------------|---------------------|--|----------------|--|
|  <p>16, 7875 - 57 STREET SE CALGARY, ALBERTA, CANADA T2C 5K7 www.globalte.com</p> | INLET PRESSURE | kPa (psig) min | | kPa (psig) max | |
| | PRESSION D'ENTRÉE | | | | |
|  <p>Intertek 5024343</p> <p>CONFORMS TO ANSI/CAN/UL/ULC STD 2200</p> | CONSUMPTION HHV | kW (Btu/h) min | | kW (Btu/h) max | |
| | CONSOMMATION PCS | | | | |
|  <p>5024343</p> <p>CONFORMS TO ANSI/CAN/UL/ULC STD 2200</p> | FUEL TYPE | TYPE DE COMBUSTIBLE | | | |
| | OUTPUT RATING @40°C | V φ HZ | | kVA COS φ | |
| <p>SEE INSTRUCTION MANUAL FOR OPERATION RAINPROOF UNIT, FOR OUTDOOR USE ONLY REPORTEZ-VOUS AU MANUEL D'UTILISATION EQUIPEMENT RESISTANT A LA PLUIE, POUR USAGE EXTERIEUR UNIQUEMENT</p> | DC OUTPUT (OPTIONAL) | V | | W | |
| | SORTIE CC (EN OPTION) | | | | |
| <p>302785 Rev 4</p> | MAX UNBALANCED LOAD | W | | RPM | |
| | CHARGE DÉSÉQUILIBRÉE MAX | | | TR/MIN | |
| | MODEL NUMBER | NUMÉRO DE MODÈLE | | | |
| | SERIAL NUMBER | NUMÉRO DE SÉRIE | | | |

Figure 3-1 – Data Plate




Figure 3-2 – MX Model Tree

The data plate shows important information about the MX Power Generator and can be used as a quick reference point when performing service or contacting GPT with questions. It is located on the inside of the electrical panel cabinet door. When contacting GPT, indicate both the complete Model Number and Serial Number of your MX unit.

The information listed on the data plate are as follows:

- | | |
|----------------------|---|
| Consumption HHV | Minimum and maximum heating values permitted. |
| Fuel Type | The type of fuel that the MX unit’s fuel system is designed for L = Propane; N = Natural Gas |
| Output Rating @ 40°C | Nominal power output of the MX unit at 40°C (104°F) |
| DC Output | DC Power output if option is installed |
| Max Unbalanced Load | Maximum unbalanced load. Exceeding this load can cause the alternator to deteriorate. |
| Model Number | Model number of the MX unit (Refer to Model Tree in Figure 3-2) |
| Serial Number | The unique number assigned to the MX unit for traceability. |

4 RECOMMENDED MAINTENANCE INTERVALS

NOTE: Oil change interval is dependent on many factors, such as number of engine starts, gas quality, average engine load, and more. We recommend taking periodic oil samples and getting them analyzed to verify validity of the recommended service intervals.

Table 1 - Maintenance Schedule

| SYSTEM SERVICE | EVERY 2,250 HOURS | EVERY 9,000 HOURS | EVERY 18,000 HOURS | EVERY 27,000 HOURS |
|---|-------------------------|-------------------------|--------------------------|--------------------------|
| Change engine oil** | ** | X | X | X |
| Change oil filter | | X | X | X |
| Change spark plugs | | X | X | X |
| Check valve clearance | | X | X | X |
| Change enclosure filter* | * | X | X | X |
| Change primary radial air filter* | * | X | X | X |
| Change secondary radial air filter | | | | X |
| Apply valve cleaner treatment | | X | | |
| Change O2 sensor | | X | X | X |
| Check CCV hoses are clear | | X | X | X |
| Check compression | | X | X | X |
| Check water pump (leaks / bearing) | | X | X | X |
| Change coolant** | ** | ** | X | ** |
| Service thermostatic valve | | | X | |
| Change water pump | | | X | |
| Change spark plug wire | | | | X |
| Change ignition coils | | | | X |
| Check fuel line for leaks | X | X | X | X |
| Clean electrical contacts | | X | X | X |
| Tighten electrical connections | | X | X | X |
| Reset maintenance hours | | X | X | X |
| <p>*Check enclosure and primary air filters every 2,250 hours. Replace at least every 9,000 hours **Check oil and coolant levels every 2,250 hours and top up as required. Replace coolant at least every 18,000 hours.</p> | | | | |

5 RECOMMENDED PARTS FOR SERVICE

Table 2 - Maintenance Materials

| SERVICE INTERVAL | QTY | GPT PN | DESCRIPTION |
|---|--------|--------------------------------|--------------------------------------|
| 303142 – MX Filter and Top Up Kit: 2,250 Hours For every 2,250 hours outside of 9,000, 18,000, and 27,000 hours | 1 | 302704 | FILTER, AIR, 12x12x2, MERV9 |
| | 1 | 302756 | AIR FILTER, PRIMARY RADIAL SEAL |
| | 1 | 303046 | OIL, ENGINE, SYNTHETIC, 1 GAL, 15W40 |
| | 1 | 303045 | COOLANT, 1 GAL, 60/40 EG, VCS |
| 303143 – MX Maintenance Kit: 9,000 Hours | 1 | 302732 | FILTER, OIL |
| | 2 | 304653 | OIL, ENGINE, SYNTHETIC, 5 GAL, 15W40 |
| | 3 | 302731 | SPARK PLUG |
| | 1 | 302733 | SENSOR, O2, PRE-CAT EXHAUST, MX |
| | 1 | 302704 | FILTER, AIR, 12x12x2, MERV9 |
| | 1 | 302756 | AIR FILTER, PRIMARY RADIAL SEAL |
| | 1 | 303045 | COOLANT, 1 GAL, 60/40 EG, VCS |
| | 1 | 303117 | GASKET, CYLINDER HEAD COVER |
| | 3 | 302745 | WASHER, SEAL, VALVE COVER |
| 1 | 305324 | CLEANER, INTAKE VALVE, GDI IVD | |
| 305991 – MX Maintenance Kit:18,000 Hours [ALUMINUM PUMP] | 1 | 302732 | FILTER, OIL |
| | 2 | 304653 | OIL, ENGINE, SYNTHETIC, 5 GAL, 15W40 |
| | 3 | 302731 | SPARK PLUG |
| | 1 | 302733 | SENSOR, O2, PRE-CAT EXHAUST, MX |
| | 1 | 302704 | FILTER, AIR, 12x12x2, MERV9 |
| | 1 | 302756 | AIR FILTER, PRIMARY RADIAL SEAL |
| | 3 | 303045 | COOLANT, 1 GAL, 60/40 EG, VCS |
| | 1 | 305981 | PUMP, ASSY, 24V , 1" MHB, TERMINATED |
| | 1 | 306014 | KIT, SERVICE, THERMO VALVE, 180 |
| | 1 | 303117 | GASKET, CYLINDER HEAD COVER |
| | 3 | 302745 | WASHER, SEAL, VALVE COVER |
| 1 | 305324 | CLEANER, INTAKE VALVE, GDI IVD | |
| 303144 – MX Maintenance Kit:18,000 Hours [BLACK PUMP] | 1 | 302732 | FILTER, OIL |
| | 2 | 304653 | OIL, ENGINE, SYNTHETIC, 5 GAL, 15W40 |
| | 3 | 302731 | SPARK PLUG |
| | 1 | 302733 | SENSOR, O2, PRE-CAT EXHAUST, MX |
| | 1 | 302704 | FILTER, AIR, 12x12x2, MERV9 |
| | 1 | 302756 | AIR FILTER, PRIMARY RADIAL SEAL |
| | 3 | 303045 | COOLANT, 1 GAL, 60/40 EG, VCS |
| | 1 | 303606 | PUMP, ASSY, 1" MHB, 24V, TERMINATED |
| | 1 | 306014 | KIT, SERVICE, THERMO VALVE, 180 |
| | 1 | 303117 | GASKET, CYLINDER HEAD COVER |
| | 3 | 302745 | WASHER, SEAL, VALVE COVER |
| 1 | 305324 | CLEANER, INTAKE VALVE, GDI IVD | |

| | | | |
|--|---|--------|--------------------------------------|
| 303145 – MX Maintenance Kit: 27,000 Hours | 1 | 302732 | FILTER, OIL |
| | 2 | 304653 | OIL, ENGINE, SYNTHETIC, 5 GAL, 15W40 |
| | 3 | 302731 | SPARK PLUG |
| | 1 | 302733 | SENSOR, O2, PRE-CAT EXHAUST, MX |
| | 1 | 302704 | FILTER, AIR, 12x12x2, MERV9 |
| | 1 | 302756 | AIR FILTER, PRIMARY RADIAL SEAL |
| | 1 | 303045 | COOLANT, 1 GAL, 60/40 EG, VCS |
| | 3 | 302737 | COIL ASSY, IGNITION |
| | 1 | 302736 | CORD SET, RESISTIVE, SPARK PLUG |
| | 1 | 302757 | AIR FILTER, SAFETY RADIAL SEAL |
| | 1 | 303117 | GASKET, CYLINDER HEAD COVER |
| | 3 | 302745 | WASHER, SEAL, VALVE COVER |
| | 1 | 305324 | CLEANER, INTAKE VALVE, GDI IVD |

6 TOOLS REQUIRED FOR SERVICE

The following items are required to perform service and maintenance on the MX Power Generator:

- MX Power Generator Maintenance Log
- Flat blade screwdrivers (from 2 mm to 6 mm)
- Philips screwdriver
- Ratchet with #2 Philips bit (low profile)
- 1/4" wrench, socket or nut driver
- 5/16" socket or nut driver
- 5/16" wrench
- 7/16" wrench, socket or nut driver
- 2x 9/16" wrenches
- 9/16" insulated wrench
- 5/8" deep socket with 2" extension
- 7/8" wrench
- 8 mm socket with short extension
- 10 mm wrench
- 10 mm crowfoot wrench
- 13 mm socket or nut driver
- 19 mm socket
- 65 mm 14-flute Toyota-compatible oil filter wrench
- Channel locks or crescent wrench capable of opening to 1-11/16"
- Pliers
- Wire stripper/cutter
- 4x 22-18AWG butt splices
- Crimper appropriate for butt splices
- Torque wrench capable of 11nm (8 ft-lbs)
- Torque wrench capable of 18nm (13.25 ft-lbs)
- 0.008" (0.203 mm) feeler gauge
- 0.012" (0.305 mm) feeler gauge
- 3/8" hose, 36" length
- 1/2" silicone or rubber hose, 1' length minimum
- Catch tray
- 26L minimum oil disposal container
- 15L coolant disposal container
- 24L Volvo coolant VCS pre-mixed – GPT part number 303045
- Jumper wire with alligator clips
- Compression tester with 14 mm thread adapter
- Wire Brush or battery post terminal cleaning tool

7 ARRIVAL ON-SITE

Before shutting the system down for maintenance, perform the following checks while the unit is in operation:

1. Access the electrical panel using a flat blade screwdriver.
2. Inspect the electrical panel and note anything out of the ordinary on the maintenance log. Some things to look for during this initial inspection are:
 - a. Are there any alarms based on the indicators on the door?
 - b. Are there any alarms on the PLC?
 - c. Are there any breakers tripped?
 - d. Are there any signs of overheating?
 - e. Are there any signs of loose wire connections?
 - f. Are there any signs of swapped components?
3. Use the 7/16" driver to remove the front panel of the Engine Compartment.



CAUTION!

Do not use power tools to remove or install the side panel fasteners. Do not force the threads into engaging if they are not going in smoothly.

Apply anti-seize compound when re-installing the fasteners.



CAUTION!

Be careful when removing the panels. Grip both handles firmly. The removeable side panels weigh approximately 45 lb. (20.5 kg).

4. Inspect Engine Compartment, take note of anything out of the ordinary on the maintenance log. Things to look for include:
 - a. Are there any odd noises?
 - Consider the engine, coolant pump, radiator fans, circulation fans, etc.
 - b. Are there any noticeable spills or leaks?
5. Make note of the radiator wind shield spacing on the maintenance log.
6. Shut down the system by ramping down the load on the system and then pressing the STOP button to stop the generator.



CAUTION!

To avoid sudden disturbance to the generator, disconnect the loads gradually — 100 to 0% over a period of 3 minutes. This helps extend the life of the unit.

7. To ensure that the system is in lockout mode for service, set the switches and breakers as follows:
 - a. LOC/REM: LOC.
 - b. AUTO/MAN: MAN.
 - c. LOCAL ON/OFF: OFF.
 - d. Main System Breaker (Q1) and Battery Charger Breaker (Q2) in engine compartment: OFF.
 - e. Main DC Control Breakers (Q3 and Q5) inside electrical panel: OFF.
8. Close units exterior ball valve to terminate fuel supply.



CAUTION!

Before starting maintenance activities, ensure that the system is set as follows:

- 1. LOC/REM switch is in LOC position**
 - 2. AUTO/MAN switch is in MAN position**
 - 3. LOCAL ON/OFF switch is in OFF position**
-

8 AIR SYSTEM

There are two major air systems in the MX Power Generator: the air feeding the engine and the air circulation in the engine compartment. Both air systems are filtered to keep the system free of foreign debris. Both engine room and engine air filters should be periodically inspected every 2,250 hours of runtime and replaced if clogged.



Figure 8-1 – Engine Air Intake Standard (left) & Cold Ambient (right) configuration




Figure 8-2 – Engine Air Circulation

During each service or maintenance visit, check the air systems as follows:


1. Inspect the engine room filter and clear it of any debris. If dirty or the system's run time has exceeded 9,000 hours, replace this enclosure air filter (GPT part number 302704).
2. Inspect fan duct screens for any debris or blockages. If the screens appear clogged:
 - Loosen and remove the wing nuts securing the screens
 - Carefully remove the screen assembly.
 - Clean the screens thoroughly to restore proper airflow.
 - Reinstall the screen assembly.



Figure 8-3 – Enclosure Intake Duct Screen

3. Inspect the engine air intake screen located on the engine air intake elbow and clear it of any debris.
4. If included with MX unit, remove, and inspect the red engine air hose for dust build up on the inner wall, clean as required. Note this red hose is not found on cold ambient configurations of the MX.
5. Inspect the primary engine air filter. If dirt is visible, or the system’s run time has exceeded 9,000 hours, replace the primary radial seal air filter (GPT part number 302756).
6. Within the primary air filter is the secondary safety air filter. If the engine run time has exceeded 27,000 hours, then this safety radial seal air filter (GPT Part number 302757) must be replaced.

Secondary Safety Air filter



Primary Air filter

Figure 8-4 – Engine Filters

9 BATTERY SYSTEM

9.1 BATTERY INSPECTION



WARNING!

Servicing of batteries are to be performed or supervised by personnel knowledgeable of batteries and the required precautions.

Keep unauthorized personnel away from batteries.



Figure 9-1 – MX Batteries

During each maintenance and service visit, inspect the battery as follows:

1. Check battery posts for corrosion. Clean any minor corrosion with wire brush or battery terminal cleaning tool. Severe corrosion may warrant replacement.
2. Measure the voltage of each battery to verify that voltage is between 12.6 and 14.8V.
 - If a battery measures below 12.6V, further charging may be required.
 - If this minimum voltage cannot be achieved by charging, the battery needs to be replaced.
 - If the battery voltage is higher than 14.8V, it also needs replacement.
 - Replacement batteries must be Type 31 AGM, 12V, 100-105Ah (GPT part number 70862).
3. Every 9,000 hours of operation, we recommend the battery positions be swapped. This ensures the batteries stay balanced, as only one position feeds the 12 VDC starting motor. Follow the steps in the battery replacement Section 9.2, as they are applicable.
4. Ensure terminals are tight and terminal boots are in place.
5. Record battery voltages on the Maintenance log.

9.2 BATTERY REPLACEMENT

When replacing batteries, use only the batteries specified:

Type 31 AGM batteries, 12V, 100-105 Ah

These batteries are available to order from GPT. When ordering replacement batteries, please quote part number 70862.

To replace or swap batteries, follow these steps:

1. Use a 9/16" insulated wrench to loosen the battery terminals.
2. Remove wiring from the battery terminals.
3. Remove the wing nut securing the battery clamp and lift it off.
4. Swap battery positions or replace batteries as necessary.
5. Reinstall the battery clamp. The wingnut should be hand-tightened only; do not use tools or it may get overtightened.
6. Reinstall the wiring onto the battery terminals.
7. Ensure terminals are tight and terminal boots are in place.
8. Make a note of battery replacements or position swaps within the Maintenance Log.




Figure 9-2 – MX Battery Clamp



CAUTION!

To avoid overtightening, do not use tools when tightening the battery clamp wing nut. Keep them hand tight.



WARNING!

A battery presents a risk of electrical shock and high short-circuit current. The following precautions are to be observed when working on batteries:

- a. Remove watches, rings, or other metal objects.
- b. Use tools with insulated handles.
- c. Wear rubber gloves and boots.
- d. Do not lay tools or metal parts on top of batteries.
- e. Disconnect charging source prior to connecting or disconnecting battery terminals.
- f. Determine if the battery is inadvertently grounded. When inadvertently grounded, remove source of ground. Contact with any part of a grounded battery is capable of resulting in electrical shock. The risk of such shock is reduced when such grounds are removed during installation and maintenance.



WARNING!

Do not dispose of battery or batteries in a fire. The battery is capable of exploding. Do not open or mutilate the batteries. Released electrolyte has been known to be harmful to the skin and eyes and to be toxic.

10 OIL SYSTEM

As shown on the maintenance table above, an oil change needs to be performed on the MX Power Generator every 9000 hours.

Before performing an oil change, make sure that the MX Power Generator is turned off and locked out and that the fuel supply is closed at the external valve. Refer to Section 7.

Perform an oil change when oil is still warm, but not hot, to allow the oil to drain more efficiently. We recommend checking the oil system after the air and battery systems have been checked. This should leave the oil temperature at an appropriate level to allow safe and efficient oil drainage.

NOTE: Oil change interval is dependent on many factors, such as number of engine starts, gas quality, average engine load, and more. We recommend that customer take periodic oil samples and get them analyzed to verify validity of the recommended service intervals.




Figure 10-1 – Long Run Oil Configuration

1. Inspect oil hoses and crankcase ventilation hoses for damage or cracks especially near hose clamps.
2. Check all hose clamps are tight.
3. Remove lower panel.




Figure 10-2 – MX Lower Panel Grommet

4. Install rubber or silicone hose over the hose barb on the oil system ball valve. See Figure 10-3 – Oil Reservoir.
5. Place catch tray or disposal container at other end of hose to collect draining oil.
6. Open the oil fill port on the engine.
7. Use channel locks or crescent wrench to open the oil fill port on the extended runtime reservoir.
8. Open oil system ball valve and allow oil to drain.
9. Wait until the oil stops draining. Once the oil has finished draining, close the ball valve.
10. Address any leaks observed in initial system inspection.
11. Use Oil Filter Wrench to remove oil filter (turn counterclockwise).
12. Pre-lubricate the new oil filter seal by rubbing clean oil on the O-ring.
13. Install the new oil filter, GPT part number 302732, following the instructions on the filter body.
14. Add 38L (10 US Gal) of new oil to the extended runtime reservoir. Allowing time for oil to equalize to engine sump.
15. Oil level should be just below the slot under the “F” on the catch plate / full tab or just below the top of the Sight glass.




Figure 10-3 – Oil Reservoir

16. Allow a few minutes for the oil to settle in the system and top up as necessary.
17. Re-install engine oil fill port cap and extended runtime reservoir cap (if applicable).
18. Remove hose from drain barb and reinstall lower panel grommet.
19. Clean up any spills.



Only use MOBIL PEGASUS 1 15W40 engine oil with the MX PrimeGen. Failure to follow these instructions may damage the long run engine and void the unit's warranty.

11 COOLANT SYSTEM

Every 9,000 hours of runtime, check the radiator system for leaks. Before opening the radiator cap, make sure that the engine has been shut down as outlined in section 7 and the fuel supply is turned off at the external fuel valve.

After engine has been shut down for maintenance, wait at least 20 minutes for the coolant to cool down and the system to depressurize. Use the coolant reservoir tank as an indicator of the coolant level once cooled down. It should be about a ¼" below fill line if cool, and at the fill line if the engine is running or hot. Fill the coolant reservoir as required.

Radiator coolant mixtures for the MX Power Generator are as follows:

- 60/40 ethylene glycol/ distilled water mixture can be used for all MX units.
- 50/50 ethylene glycol/ distilled water can be used for MX units in warmer ambient climates that remain above -5°C (23°F).
- Volvo VCS coolant must be used to ensure extended engine life.




Figure 11-1 – Radiator Assembly

11.1 CHANGING COOLANT



Do not open the radiator cap if the radiator is hot to the touch. Allow it to cool for at least 20 minutes before proceeding.

WARNING!

1. Using a Phillips screwdriver, remove fasteners from the radiator cap cover for access to radiator cap.




Figure 11-2 – Upper Petcock Location

2. Attach 3/8" hose to coolant petcock valve (Figure 11-3 - Engine Block Petcock Location) on engine block.
3. Put hoses from both the engine block petcock and the radiator coolant lower ball valve (Figure 11-1 – Radiator Assembly) into disposal bucket.
4. Open engine block petcock valve and radiator coolant lower ball valve to drain coolant.
5. Open radiator cap and upper petcock to allow all the coolant to drain.
6. Once the coolant has been drained, close the engine block petcock valve and radiator coolant lower ball valve. Keep the upper petcock valve open.

NOTE: **If you intend to replace the pump or service the thermostatic valve, this is when to do it. Please see sections 11.2 & 11.3 for details.**




Figure 11-3 – Engine Block Petcock Location

7. Add coolant, GPT part number 303045, to system through the top of the radiator. Fill to bottom of the radiator cap neck. Close the upper petcock valve.



WARNING!

Only use Volvo VCS coolant with the MX Prime generator. Do not mix coolants. When adjusting coolant concentration or mixing new coolant, only use distilled water. Failure to follow these instructions may damage the radiator or coolant system and void the unit's warranty.

8. Take system out of service mode by setting switches and breakers as follows:
 - a. LOC/REM: LOC.
 - b. AUTO/MAN: MAN.
 - c. LOCAL ON/OFF: ON.
 - d. Main System Breaker (Q1) and Battery Charger Breaker (Q2) in engine compartment: OFF.
 - e. Main DC Control Breakers (Q3 and Q5) inside electrical panel: ON.
9. Using PLC HMI, enter Menu 10: Cold Start and activate the coolant pump. See Operation Manual Section 5.2 for details on using the HMI.




Figure 11-4 – PLC HMI

10. When the coolant pump turns on, the coolant in the radiator will begin to drop. Once the coolant in the radiator levels out, turn off the pump and refill the radiator to the radiator cap neck.
11. Repeat steps 9 and 10 until the coolant level does not drop when the pump is turned on.
12. Clamp the coolant reservoir hose connecting the coolant tank to the radiator. Fill the coolant reservoir tank to about 3/8" below the "FILL" line. Note the "FILL" line is for a hot / warmed up system.
13. Remove the clamp and allow/ensure that the coolant fills the radiator. Clamp the hose again, install the radiator cap, and then unclamp the hose.




Figure 11-5 – Filled radiator

14. Turn on the engine and allow the unit to heat up for 15 minutes or until the engine temperature is above 81°C
15. Visually check the radiator cap and all valves for any leaks.
16. Top up the coolant reservoir to the fill line if necessary.

17. Clean up any coolant spills.
18. If further maintenance is to be performed, return the switches and breakers to lock out state as follows:
 - a. LOC/REM: LOC.
 - b. AUTO/MAN: MAN.
 - c. LOCAL ON/OFF: OFF.
 - d. Main System Breaker (Q1) and Battery Charger Breaker (Q2) in engine compartment: OFF.
 - e. Main DC Control Breakers (Q3 and Q5) inside electrical panel: OFF.

11.2 REPLACING COOLANT PUMP

1. Drain coolant as described in steps 1-6 of 'Changing Coolant'.
2. Set catch tray below coolant pump.
3. Disconnect pump connectors from cable harness.
4. Remove hose clamps on the inlet and outlet of the pump.
5. Using 5mm hex drive, remove 4 mounting bolts of pump.
6. Rotate pump clockwise and work hose off outlet barb of pump.
7. Work hose off inlet barb of pump. Be careful to catch any coolant that may remain in the pump.
8. Insert inlet and outlet barb of new pump, GPT part number 305981, into appropriate hoses.
9. Replace and tighten all mounting hardware for pump.
10. Tighten hose clamps.
11. Attached pump connectors to cable harness.
12. Continue with steps 7-18 of 'Changing Coolant'.




Figure 11-6 – Coolant pump installation

11.3 SERVICING THE THERMOSTATIC VALVE

The thermostatic valve must be serviced every 18,000 hours to ensure reliable operation. To service the thermostatic valve, please order the service kit 306014 from GPT. Follow the procedure below to service the thermostatic valve.




Figure 11-7 – Thermostatic Valve Parts

1. Drain coolant as described in steps 1-6 of 'Changing Coolant'.
2. Remove the snap ring (6) and plug (7).
3. Remove the temperature element (4) and replace with new element.
4. Remove the housing O-ring (5) and replace with new O-ring.
5. Reassemble the valve by installing a new plug (7) and snap ring (6).
6. Continue with steps 7-18 of 'Changing Coolant'.

11.4 TOPPING UP THE RADIATOR FLUID

If the low-level coolant alarm activates or you notice a low coolant level during scheduled maintenance, the coolant reservoir must be refilled. Follow these steps to safely top up the coolant:

1. Open the coolant reservoir to cap located inside the engine room door.
2. Pour coolant in the tank until it hits the "Fill" line. Note: to prevent coolant overflow only fill the coolant to the fill line if the engine is still warm or running at a steady state.
3. Reinstall the coolant reservoir cap.




Figure 11-8 – Coolant Reservoir

12 ELECTRICAL SYSTEM

12.1 CUSTOMER TERMINATIONS




Figure 12-1 – Customer Wiring Terminations (3 Phase & Single-Phase Systems)

Table 3 - Customer Wiring Connections (3 Phase & Single-Phase Systems)

| CONNECTION | DESCRIPTION | VOLTAGE OUTPUT |
|--------------|--|---|
| (X5) | AC Load Recommend Cable Size: 10 AWG, Copper, 90C | 120/240 V _{AC} : 1PH 110/220 V _{AC} : 1 PH 120/208 V _{AC} : 3 PH |
| (X6) 3, 4 | Remote On/Off | Dry Contact |
| (X6) 7, 8 | External Emergency Shutdown (ESD) | Dry Contact |
| (X6) 11, 12 | Alarm From SCADA | Dry Contact |
| (X6) 15, 16 | Alarm to SCADA | Dry Contact |
| (X6) 19, 20 | Customer Load Status | Dry Contact |
| (X6) 23, 24 | Remote Start | Dry Contact |
| (X6) 27, 28 | Out of Service Status | Dry Contact |
| (X6) 31, 32 | <i>Spare, reserved for future use</i> | |
| (X6) 35, 36 | Modbus RS-485 terminals | |
| (X6) 39, 40 | Signal Ground Terminals | |
| (X6) 43, 44 | Remote ON/ OFF | Dry Contact |
| (X7) 2,4,6,8 | Optional 24/48 V _{DC} Converter terminals Recommended Cable Size: 6-2 AWG, Copper, 90C | Nominal 24/48 V _{DC} |

Refer to MX Manual 305876 for operational instructions of all SCADA dry contacts on terminal block X6.



Ensure that the correct polarity is followed. Incorrect polarity may cause damage to the generator or customer equipment.

WARNING!

12.2 SENSOR LOCATIONS

Table 4 - List of Sensors

| Sensor # | GPT PN # | Description |
|----------|----------|--|
| 1 | 303451 | Engine Enclosure Temperature Sensor |
| 2 | 303451 | Engine Coolant Outlet Temperature Sensor |
| 3 | 304528 | Engine Coolant Temperature Sensor |
| 4 | 303451 | Engine Coolant Inlet Temperature Sensor |
| 5 | 61849 | Fuel Sensor / Switch |
| 6 | 302753 | Oil Pressure Sensor / Switch |
| 7 | 302735 | Crank Position Sensor |
| 8 | 302734 | Exhaust Temperature Sensor |
| 9 | 302733 | Exhaust O ₂ Sensor |
| 10 | 300862 | PLC (Electrical Box) Temperature Sensor |
| 11 | 303451 | Ambient Temperature Sensor |
| 12 | 305469 | Low Coolant Level Sensor |
| 13 | 303646 | Thermal Fuse (Electrical Enclosure) |
| 14 | 303646 | Thermal Fuse (Engine Room) |




Figure 12-2 – MX Sensor Locations | Front Panel




Figure 12-3 – MX Sensor Locations | Back Panel




Figure 12-4 – MX Sensor Locations | Side Panel




Figure 12-5 – MX Sensor Locations | Electrical Cabinet

12.3 CURRENT PROTECTION

The table below outlines circuit breakers and fuses are present on MX Prime Gen.

Table 5 - Circuit Breaker and Fuse Protection List

| MARK | FUNCTION | RATING & TYPE | LOCATION |
|------|--|--|----------------------|
| Q1 | Main Breaker | 1- ϕ : 40A, 2P 3- ϕ : 40A, 3P | AC Breakers |
| Q2 | Battery Charger Breaker | 1- ϕ : 10A, 2P 3- ϕ : 10A, 3P | AC Breakers |
| Q3 | Main DC Breaker | 30A, 1P | DC Breakers |
| Q4 | External AC Breaker | 20A, 1P | AC Breakers |
| Q5 | DC Control Breaker | 10A, 1P | DC Breakers |
| Q7 | Customer AC Load Breaker | 1- ϕ : 32A, 2P 3- ϕ : 30A, 3P | AC Breakers |
| Q8 | Receptacle Breaker | 3A, 1P | AC Breakers |
| Q9 | AC/DC Power Supply Breaker (Option) | 10A, 2P | AC Breakers |
| Q10 | Coolant Pump Breaker | 30A, 1P 15A, 1P (Option) | DC Breakers |
| F1 | L1 Voltage Sensing | 1A, 250VAC, Glass | AC Fuses |
| F2 | L2 Voltage Sensing | 1A, 250VAC, Glass | AC Fuses |
| F3 | L3 Voltage Sensing - 3- ϕ Only | 1A, 250VAC, Glass | AC Fuses |
| F4 | DC Heat Trace | 3A, 250VAC, Glass | DC Fuse |
| F5 | 24-24 VDC G4 Converter, Solenoid Valve | 5A, 32VDC, Blade | J9 DC Power Module |
| F7 | 24-24 VDC G6 Converter, Control | 5A, 32VDC, Blade | J9 DC Power Module |
| F8 | J9 PCB Input Power | 5A, 32VDC, Blade | J9 DC Power Module |
| F10 | Radiator Fan 1 | 7.5A, 32VDC, Blade | J11 Fuse Module |
| F11 | Radiator Fan 2 | 7.5A, 32VDC, Blade | J11 Fuse Module |
| F12 | Intake Fan | 7.5A, 32VDC, Blade | J11 Fuse Module |
| F13 | Exhaust Fan | 7.5A, 32VDC, Blade | J11 Fuse Module |
| F14 | ECU | 5A, 32VDC, Blade | J9 DC Power Module |
| F16 | PLC and Modem | 3A, 32VDC, Blade | J9 DC Power Module |
| F17 | Electrical Enclosure Fan / Power Meter | 2A, 32VDC, Blade | J9 DC Power Module |
| F18 | Thermal Fuse, Electrical Enclosure | 10A, 84°C, 250V | Electrical Enclosure |

| MARK | FUNCTION | RATING & TYPE | LOCATION |
|------|---------------------------|-------------------|--------------------|
| F19 | Thermal Fuse, Engine Room | 10A, 84°C, 250V | Engine Room |
| F20 | 24-24 VDC G7 Converter | 5A, 32VDC, Blade | J9 DC Power Module |
| F21 | 5 VDC Supply Branch 1 | 1A, 250VAC, Glass | J9 DC Power Module |
| F22 | 5 VDC Supply Branch 2 | 1A, 250VAC, Glass | J9 DC Power Module |
| F23 | Raspberry Pi Module | 2A, 250VAC, Glass | J9 DC Power Module |




Figure 12-6 – Location of Circuit Breakers, Fuses, J9/J11 Modules, and Spare Fuse Holder




Figure 12-7 – Layout and Fuse Numbers of DC Power Module J9 and Fuse Module J11

12.4 THERMAL FUSE LOCATIONS




Figure 12-8 – #13 Thermal Fuse (Electrical Room)



Figure 12-9 – #14 Thermal Fuse (Engine Room)

12.5 CHECKING ELECTRICAL CONNECTIONS

While the MX is powered down and all breakers are off:

- Check all screw terminals and ensure connections are still tight.
- Check all fuses for continuity and replace as required. See Table 5.
- Visually inspect all breakers for damage.
- Check all spade connections for signs of damage or wear. Ensure they are all still snug fitting.

13 CHECKING AND ADJUSTING VALVE CLEARANCES

Assessing and adjusting the valves must be done when the engine is cold to ensure proper clearances.

1. Use 13mm driver and Philips driver to remove the crankshaft pulley cover guard.
2. Use 10mm wrench to remove valve cover.
3. Remove boots from spark plugs and drape off to the side.
4. Use 5/8" socket to remove spark plugs.
5. Use 19mm socket to rotate crankshaft clockwise until cylinder 1 is in compression Top Dead Center (TDC). Cylinder 1 is closest to the pulley. Cylinder 1 is in compression when both the intake and exhaust valves are closed (rocker arms in the up position) and the markings on the pulley and engine block aligned as shown.




Figure 13-1 – Pulley & Engine Block Marking Alignment

6. Measure clearances of the valves marked 'X' below:

| Cylinder Number | Valves | |
|-----------------|--------|---------|
| | Intake | Exhaust |
| 1 | X | X |
| 2 | O | X |
| 3 | X | O |

- a. To measure clearances, first use the 0.008" (0.203mm) feeler gauge. It should easily be inserted between the rocker arm and valve stem as shown.




Figure 13-2 – Rocker Arm & Valve Stem

- b. Follow with the 0.012" (0.305mm) feeler gauge. This should not be able to insert between the rocker arm and valve stem.
- c. Adjust valves that do not meet this specification.
 - Hold the valve adjustment screw in place with flat blade screwdriver and loosen the set nut with the 10mm wrench.
 - Rotate adjustment screw until the 0.008" feeler gauge can be inserted between the rocker arm and valve stem.
 - Hold the screw in place and tighten set nut to 11Nm with a 10mm crowfoot wrench.
 - Verify that the 0.008" gauge can be inserted, and the 0.012" gauge cannot.
7. Use 19mm socket to rotate crankshaft 360° clockwise, bringing cylinder 1 to exhaust top dead center. Align markings on pulley and engine block as before.



Figure 13-3 – Pulley & Engine Block Marking Alignment

8. Measure clearances of the valves marked 'O' above, adjust as required as stated in step 6.
9. Rotate engine two full revolutions to ensure no binding or tightness.




Figure 13-4 – Rocker Arm & Valve Stem



Tighten the lock nuts of the setting screws after adjusting the valve clearance. Tightening torque is 11 N-m.

WARNING!

10. Remove and replace valve cover seal washers, GPT part number 302745.
11. Remove and replace cylinder head cover gasket, GPT part number 303117
12. Reinstall valve cover.
13. Reinstall the crankshaft pulley cover guard.

14 CYLINDER COMPRESSION TEST

1. Ensure no fuel is available to the system.
1. Take system out of service mode by setting switches and breakers as follows:
 - a. LOC/REM: LOC.
 - b. AUTO/MAN: MAN.
 - c. LOCAL ON/OFF: ON.
 - d. Main System Breaker (Q1) and Battery Charger Breaker (Q2) in engine compartment: ON.
 - e. Main DC Control Breakers (Q3 and Q5) inside electrical panel: ON.
2. Remove rubber boot from fuel pressure switch and install jumper wire across switch contacts.



Figure 14-1 – Jumper Wire Placement

3. Disconnect ignition wire from spark plug #1.
4. Use 5/8" deep socket to remove the spark plug.
5. Thread compression tester into spark plug port.
6. Press start button and allow engine to crank until compression pressure reading stabilizes.
7. Press stop button.

8. Record the pressure reading in the maintenance log, then consult the table below to determine the appropriate action based on the lowest value recorded across the three cylinders during the compression test:

Table 6 - Cylinder Compression Test Reference Table

| COMPRESSION TEST VALUE (LOWEST OF THE 3 CYLINDERS) | RESULT/ACTION |
|---|--|
| > 140 PSI (MAX 232 PSI) | NEW ENGINE, NO ACTION |
| 130 – 140 PSI | EXPECTED VALUE FOR WORKED IN ENGINE, NO ACTION |
| 120 – 130 PSI | EXPECTED VALUE FOR ENGINES WITH OVER 9000 HOURS RUN TIME, RECOMMEND VALVE CLEANER TREATMENT |
| 100 – 120 PSI | PERFORM LEAK-DOWN TEST TO DETERMINE IF THE ISSUE IS A VALVE LEAK OR PISTON LEAK. RECOMMEND VALVE CLEANER TREATMENT IF VALVE LEAK IS SUSPECTED. * |
| < 100 PSI | CONTACT GPT CUSTOMER SERVICE FOR TROUBLESHOOTING/REPAIR |

* Contact GPT customer service if piston leak is suspected, or if the valve cleaner treatment does not work.

Note: GPT recommends cleaning the engine with valve cleaner (GPT PN# 305324) when cylinder pressure drops below 130 PSI. See Section 16 for details on the valve cleaner treatment.

9. Remove compression tester from port and reinstall spark plug.
10. Torque the spark plug to 18Nm.
11. Repeat steps 3-10 for spark plug #2 & #3.
12. Remove jumper wire from pressure switch and re-install rubber boot.

15 IGNITION SYSTEM




Figure 15-1 – MX Ignition System

15.1 SPARK PLUG REPLACEMENT

1. Disconnect ignition wires from spark plug.
2. Use 5/8" socket to remove old spark plug.
3. Thread new spark plug, GPT part number 302731, into engine block by hand.
4. Torque to 18Nm.
5. Repeat for remaining spark plugs.

15.2 SPARK PLUG WIRE REPLACEMENT

1. Disconnect boots from spark plugs.
2. Disconnect boots from ignition coils.
3. Install new wires, GPT part number 302736.

15.3 CHANGE IGNITION COILS

4. Use 8 mm socket to remove mounting fasteners.
5. Remove ignition coil.
6. Install new ignition coil, GPT part number 302737, and reinstall fasteners.

16 VALVE CLEANER TREATMENT

The valve cleaner treatment should be performed based on recommendations from Table 6 to clean the engine intake valves.

NOTE: Replace O2 sensor (Section 17) after valve cleaner treatment is performed.

NOTE: Please ensure both MX side panels are open before completing this procedure. Proper PPE (gloves and glasses) should be worn, and all safety instructions listed on the valve cleaner must be followed.

1. Turn off the engine and allow for it to cool for approximately 30 mins. Remove air intake elbow.




Figure 16-1 – Air Intake Elbow Location

2. Turn on the engine after removing elbow and let it run for few minutes. (Note: If possible, add 1-2 kW load).
3. With the engine running, take the valve cleaner (GPT PN# 305324) and spray the valve cleaner into the engine at the location where the air intake elbow was removed for 1-2 seconds. The engine speed should increase as the valve cleaner is sprayed. (Note: If engine RPM becomes unstable, add load or restart the unit).
4. Wait for the engine speed to stabilize.
5. Repeat steps 3-4 until the valve cleaner is used up. This process should take approximately 45 minutes to complete.
6. Let the engine run for approximately 30 minutes.
7. Turn off engine and reinstall the air intake elbow.

17 REPLACING O₂ SENSOR

NOTE: Ensure the Valve Cleaner Treatment (Section 16) has been completed before replacing O₂ sensor.




Figure 17-1 – O₂ Sensor Location

1. Power down the MX and allow it to cool for at least 1 hour.
2. Remove the exhaust blanket.
3. Use a flat blade screwdriver to release the retaining clip on the connector so that the O₂ sensor can be disconnected from the wire harness.
4. Use 7/8" wrench to remove O₂ Sensor from exhaust line.
5. Apply small amount of high temperature anti seize to threads on new O₂ Sensor and install into exhaust line.
6. Connect sensor to wire harness.
7. Re-install exhaust jacket.

18 ZERO GOVERNOR TROUBLESHOOTING

The zero governor is a precise regulator used to supply the throttle body with consistent fuel pressure. It brings the 55 – 138 inH₂O (2 – 5 PSI) supply pressure down to 1.55 inH₂O (0.056 PSI) for natural gas and 0.50 inH₂O (0.018 PSI) for propane. The valve seat can get dirty over time, causing poor regulation and over fueling, which results in hard start up conditions.




Figure 18-1 – Zero Governor Location and Plug Location

If there are issues with the MX start-up, the zero governor may be dirty/clogged. The zero governor can get clogged due to various reasons, with the most prominent being fuel gas contamination. To check if the zero governor is operating correctly, a pressure test must be performed. Follow the steps below to perform a pressure test on the zero governor.

1. Disconnect load via Q 6/7 breakers. Leave disconnected for the remainder of test.
2. Shut off the engine by pressing the “STOP” button on the electrical enclosure.
3. Remove the plug connected to the zero governor.
4. Install a PX 409 pressure transducer (or equivalent) to the 1/2” tube test port. The pressure transducer must be able to read in inH₂O.
5. Ensure fuel pressure is between 2 – 5 PSIG going into the zero governor.
6. Press “START” button on MX electrical enclosure. The engine will start cranking, and may start. Observe the pressure reading from the pressure transducer. The fuel pressure should be 1.55 +/- 0.20 inH₂O for natural gas and 0.50 +/- 0.20 inH₂O for propane.
 - a. If after two minutes the fuel pressure stays within the correct range, the zero governor is operating as expected. The engine can be shut down.
 - b. If after two minutes the fuel pressure is not within the correct range, there may be an issue with the zero governor. Please contact GPT Customer Service for support.

If the zero governor is found to be operating correctly and startup can still not be achieved, please contact GPT Customer Service for support.

19 MAINTENANCE HOURS RESET

1. Take system out of service mode by setting switches and breakers as follows:
 - a. LOC/REM: LOC.
 - b. AUTO/MAN: MAN.
 - c. LOCAL ON/OFF: ON.
 - d. Main System Breaker (Q1) and Battery Charger Breaker (Q2) in engine compartment: ON.
 - e. Main DC Control Breakers (Q3 and Q5) inside electrical panel: ON.
2. Navigate the LCD on PLC to **Menu 9.13 – Maintenance Hours Reset** by using the five button keys, press and hold ENTER key for five seconds to reset

20 MX PRIMEGEN SITE INSTALLATION & COMMISSIONING REPORT

To receive a full warranty on the MX, please fill and sign and send both pages of the site installation and commissioning report. Send a picture, scan, or copy to customer.service@globalte.com.

| MX UNIT INFORMATION | | | |
|---------------------|--|-----------------|--|
| Serial Number | | Fuel Type | |
| Model Number | | Regulator (Y/N) | |

| SITE INFORMATION | | | |
|---------------------|--|----------------|--|
| Site Name | | | |
| Address | | | |
| City | | State/Province | |
| Zip (if applicable) | | Country | |

| SITE CONTACT & COMPANY INFORMATION | | | |
|------------------------------------|--|-------|--|
| Company Name | | | |
| Contact Name | | | |
| Phone | | Email | |

| COMMISSIONING COMPANY INFORMATION (IF DIFFERENT THAN COMPANY CONTACT) | | | |
|---|--|-------|--|
| Company Name | | | |
| Contact Name | | | |
| Phone | | Email | |



WARNING!

Before beginning any work on the MX power generator, read the installation, operation, and maintenance (IOM) manual 305876 thoroughly and pay special attention to all safety instructions. Ensure that the MX is installed as per Section 4 of the MX IOM manual 305876.

- Unit inspected for possible damage from shipping. Any findings documented and reported
- MX unit is secured to a solid level surface. (IOM section 4.1)
- MX unit is installed in an unclassified location and meets all local regulations
- Site maintains a minimum 1 m [40"] clearance from all sides of the unit. (IOM section 4.1.1)
- Intended fuel supply meets requirements (IOM section 4.1.2)
- Exhaust silencer assembly installed, and all exhaust clamps tightened (IOM section 4.4)
- Exhaust Cover has been installed (IOM section 4.4)
- Batteries voltage checked and connected (IOM section 4.4.1 & Service manual section 9)
- Oil and coolant/radiator lines checked for damage or leaks
- Coolant levels checked and filled as required (IOM section 4.4.2 & Service manual section 11)
- Oil levels checked and topped up as required (Service manual section 10)
- Fuel line installed and leak checked (IOM section 4.4.3)
- Electrical connections are tight and terminated correctly (IOM section 4.4.4)
- Confirm Supplied fuel pressure to MX is 2-5 PSI (or 10-28 PSI with optional regulator)
- Air filters installed and are clean (Service manual section 8)
- All customer wiring connections made (IOM section 4.4.4)
- MX unit is grounded using supplied grounding Stud(s) on the skid
- Radiator wind-shield gap has been adjusted (IOM section 4.4.6)
- An external 120V AC power source may be required to charge the batteries or pre-warm the engine before startup if the temperature is below -5°C [23°F] (IOM section 6.2)
- Start engine (IOM section 6)
- Confirm engine ramps up and maintains proper engine speed (1800 for 60 Hz or 1500 for 50 Hz)
- Confirm external 120V AC power source is unplugged
- Confirm radiator fans turn on / cycle when engine temperature gets above 82°C [180°F]
- Turn on customer load. Confirm customer load is receiving power. The load should be gradually increased
- Confirm IOT is communicating (not applicable if cellular service is not available)

Notes:

| | | |
|---------------------------|--------------------------------|------|
| Site Representative Name | Site Representative Signature | Date |
| Commissioning Person Name | Commissioning Person Signature | Date |

21 MX GENERATOR MAINTENANCE LOG

| | | | |
|----------------------------|----------------------|---------------------------|----------------------|
| Model Number: | | Serial Number: | |
| Service Date: | | MX Runtime: | |
| Wind Shield Distance: | | | |
| Switch Settings | LOC/REM | | |
| | AUTO/MAN | | |
| | LOCAL | | |
| | ON/OFF | | |
| Radial Air Filter | Inspected / Replaced | | |
| Safety Radial Air Filter | Inspected / Replaced | | |
| Enclosure Filter | Inspected / Replaced | | |
| Batteries | Inspected / Replaced | | |
| Battery Voltage | Battery 1: | Above 12.6V & Below 14.8V | |
| | Battery 2: | Above 12.6V & Below 14.8V | |
| Engine Oil | Inspected / Replaced | | |
| Engine Oil Filter | Replaced | | |
| Coolant | Inspected / Replaced | | |
| Coolant Pump | Inspected / Replaced | | |
| Crankcase Vent Hoses | Inspected / Replaced | | |
| O2 Sensor | Replaced | | |
| Valve Clearances | Cylinder Number | Valves | |
| | | Intake | Exhaust |
| | 1 | Inspected / Adjusted | Inspected / Adjusted |
| | 2 | Inspected / Adjusted | Inspected / Adjusted |
| 3 | Inspected / Adjusted | Inspected / Adjusted | |
| Spark Plug 1 | Inspected / Replaced | | |
| Spark Plug 2 | Inspected / Replaced | | |
| Spark Plug 3 | Inspected / Replaced | | |
| Spark Plug Wire 1 | Inspected / Replaced | | |
| Spark Plug Wire 2 | Inspected / Replaced | | |
| Spark Plug Wire 3 | Inspected / Replaced | | |
| Ignition Coil 1 | Inspected / Replaced | | |
| Ignition Coil 2 | Inspected / Replaced | | |
| Ignition Coil 3 | Inspected / Replaced | | |
| Cylinder 1 Compression: | Refer to Table 8 | | |
| Cylinder 2 Compression: | Refer to Table 8 | | |
| Cylinder 3 Compression: | Refer to Table 8 | | |
| Notes: | | | |

| | | | |
|--------------------------|----------------------|---------------------------|----------------------|
| Model Number: | | Serial Number: | |
| Service Date: | | MX Runtime: | |
| Wind Shield Distance: | | | |
| Switch Settings | LOC/REM | | |
| | AUTO/MAN | | |
| | LOCAL ON/OFF | | |
| Radial Air Filter | Inspected / Replaced | | |
| Safety Radial Air Filter | Inspected / Replaced | | |
| Enclosure Filter | Inspected / Replaced | | |
| Batteries | Inspected / Replaced | | |
| Battery Voltage | Battery 1: | Above 12.6V & Below 14.8V | |
| | Battery 2: | Above 12.6V & Below 14.8V | |
| Engine Oil | Inspected / Replaced | | |
| Engine Oil Filter | Replaced | | |
| Coolant | Inspected / Replaced | | |
| Coolant Pump | Inspected / Replaced | | |
| Crankcase Vent Hoses | Inspected / Replaced | | |
| O2 Sensor | Replaced | | |
| Valve Clearances | Cylinder Number | Valves | |
| | | Intake | Exhaust |
| | 1 | Inspected / Adjusted | Inspected / Adjusted |
| | 2 | Inspected / Adjusted | Inspected / Adjusted |
| | 3 | Inspected / Adjusted | Inspected / Adjusted |
| Spark Plug 1 | Inspected / Replaced | | |
| Spark Plug 2 | Inspected / Replaced | | |
| Spark Plug 3 | Inspected / Replaced | | |
| Spark Plug Wire 1 | Inspected / Replaced | | |
| Spark Plug Wire 2 | Inspected / Replaced | | |
| Spark Plug Wire 3 | Inspected / Replaced | | |
| Ignition Coil 1 | Inspected / Replaced | | |
| Ignition Coil 2 | Inspected / Replaced | | |
| Ignition Coil 3 | Inspected / Replaced | | |
| Cylinder 1 Compression: | Refer to Table 8 | | |
| Cylinder 2 Compression: | Refer to Table 8 | | |
| Cylinder 3 Compression: | Refer to Table 8 | | |
| Notes: | | | |

| | | | |
|--------------------------|----------------------|---------------------------|----------------------|
| Model Number: | | Serial Number: | |
| Service Date: | | MX Runtime: | |
| Wind Shield Distance: | | | |
| Switch Settings | LOC/REM | | |
| | AUTO/MAN | | |
| | LOCAL ON/OFF | | |
| Radial Air Filter | Inspected / Replaced | | |
| Safety Radial Air Filter | Inspected / Replaced | | |
| Enclosure Filter | Inspected / Replaced | | |
| Batteries | Inspected / Replaced | | |
| Battery Voltage | Battery 1: | Above 12.6V & Below 14.8V | |
| | Battery 2: | Above 12.6V & Below 14.8V | |
| Engine Oil | Inspected / Replaced | | |
| Engine Oil Filter | Replaced | | |
| Coolant | Inspected / Replaced | | |
| Coolant Pump | Inspected / Replaced | | |
| Crankcase Vent Hoses | Inspected / Replaced | | |
| O2 Sensor | Replaced | | |
| Valve Clearances | Cylinder Number | Valves | |
| | | Intake | Exhaust |
| | 1 | Inspected / Adjusted | Inspected / Adjusted |
| | 2 | Inspected / Adjusted | Inspected / Adjusted |
| 3 | Inspected / Adjusted | Inspected / Adjusted | |
| Spark Plug 1 | Inspected / Replaced | | |
| Spark Plug 2 | Inspected / Replaced | | |
| Spark Plug 3 | Inspected / Replaced | | |
| Spark Plug Wire 1 | Inspected / Replaced | | |
| Spark Plug Wire 2 | Inspected / Replaced | | |
| Spark Plug Wire 3 | Inspected / Replaced | | |
| Ignition Coil 1 | Inspected / Replaced | | |
| Ignition Coil 2 | Inspected / Replaced | | |
| Ignition Coil 3 | Inspected / Replaced | | |
| Cylinder 1 Compression: | Refer to Table 8 | | |
| Cylinder 2 Compression: | Refer to Table 8 | | |
| Cylinder 3 Compression: | Refer to Table 8 | | |
| Notes: | | | |

| | | | |
|--------------------------|----------------------|---------------------------|----------------------|
| Model Number: | | Serial Number: | |
| Service Date: | | MX Runtime: | |
| Wind Shield Distance: | | | |
| Switch Settings | LOC/REM | | |
| | AUTO/MAN | | |
| | LOCAL ON/OFF | | |
| Radial Air Filter | Inspected / Replaced | | |
| Safety Radial Air Filter | Inspected / Replaced | | |
| Enclosure Filter | Inspected / Replaced | | |
| Batteries | Inspected / Replaced | | |
| Battery Voltage | Battery 1: | Above 12.6V & Below 14.8V | |
| | Battery 2: | Above 12.6V & Below 14.8V | |
| Engine Oil | Inspected / Replaced | | |
| Engine Oil Filter | Replaced | | |
| Coolant | Inspected / Replaced | | |
| Coolant Pump | Inspected / Replaced | | |
| Crankcase Vent Hoses | Inspected / Replaced | | |
| O2 Sensor | Replaced | | |
| Valve Clearances | Cylinder Number | Valves | |
| | | Intake | Exhaust |
| | 1 | Inspected / Adjusted | Inspected / Adjusted |
| | 2 | Inspected / Adjusted | Inspected / Adjusted |
| 3 | Inspected / Adjusted | Inspected / Adjusted | |
| Spark Plug 1 | Inspected / Replaced | | |
| Spark Plug 2 | Inspected / Replaced | | |
| Spark Plug 3 | Inspected / Replaced | | |
| Spark Plug Wire 1 | Inspected / Replaced | | |
| Spark Plug Wire 2 | Inspected / Replaced | | |
| Spark Plug Wire 3 | Inspected / Replaced | | |
| Ignition Coil 1 | Inspected / Replaced | | |
| Ignition Coil 2 | Inspected / Replaced | | |
| Ignition Coil 3 | Inspected / Replaced | | |
| Cylinder 1 Compression: | Refer to Table 8 | | |
| Cylinder 2 Compression: | Refer to Table 8 | | |
| Cylinder 3 Compression: | Refer to Table 8 | | |
| Notes: | | | |

| | | | |
|--------------------------|----------------------|---------------------------|----------------------|
| Model Number: | | Serial Number: | |
| Service Date: | | MX Runtime: | |
| Wind Shield Distance: | | | |
| Switch Settings | LOC/REM | | |
| | AUTO/MAN | | |
| | LOCAL ON/OFF | | |
| Radial Air Filter | Inspected / Replaced | | |
| Safety Radial Air Filter | Inspected / Replaced | | |
| Enclosure Filter | Inspected / Replaced | | |
| Batteries | Inspected / Replaced | | |
| Battery Voltage | Battery 1: | Above 12.6V & Below 14.8V | |
| | Battery 2: | Above 12.6V & Below 14.8V | |
| Engine Oil | Inspected / Replaced | | |
| Engine Oil Filter | Replaced | | |
| Coolant | Inspected / Replaced | | |
| Coolant Pump | Inspected / Replaced | | |
| Crankcase Vent Hoses | Inspected / Replaced | | |
| O2 Sensor | Replaced | | |
| Valve Clearances | Cylinder Number | Valves | |
| | | Intake | Exhaust |
| | 1 | Inspected / Adjusted | Inspected / Adjusted |
| | 2 | Inspected / Adjusted | Inspected / Adjusted |
| 3 | Inspected / Adjusted | Inspected / Adjusted | |
| Spark Plug 1 | Inspected / Replaced | | |
| Spark Plug 2 | Inspected / Replaced | | |
| Spark Plug 3 | Inspected / Replaced | | |
| Spark Plug Wire 1 | Inspected / Replaced | | |
| Spark Plug Wire 2 | Inspected / Replaced | | |
| Spark Plug Wire 3 | Inspected / Replaced | | |
| Ignition Coil 1 | Inspected / Replaced | | |
| Ignition Coil 2 | Inspected / Replaced | | |
| Ignition Coil 3 | Inspected / Replaced | | |
| Cylinder 1 Compression: | Refer to Table 8 | | |
| Cylinder 2 Compression: | Refer to Table 8 | | |
| Cylinder 3 Compression: | Refer to Table 8 | | |
| Notes: | | | |

| | | | |
|-------------------------|----------------------|---------------------------|----------------------|
| Model Number: | | Serial Number: | |
| Service Date: | | MX Runtime: | |
| Wind Shield Distance: | | | |
| Switch Settings | LOC/REM | | |
| | AUTO/MAN | | |
| | LOCAL ON/OFF | | |
| Radial Air Filter | Inspected / Replaced | | |
| Safety Radial Filter | Inspected / Replaced | | |
| Enclosure Filter | Inspected / Replaced | | |
| Batteries | Inspected / Replaced | | |
| Battery Voltage | Battery 1: | Above 12.6V & Below 14.8V | |
| | Battery 2: | Above 12.6V & Below 14.8V | |
| Engine Oil | Inspected / Replaced | | |
| Engine Oil Filter | Replaced | | |
| Coolant | Inspected / Replaced | | |
| Coolant Pump | Inspected / Replaced | | |
| Crankcase Vent Hoses | Inspected / Replaced | | |
| O2 Sensor | Replaced | | |
| Valve Clearances | Cylinder Number | Valves | |
| | | Intake | Exhaust |
| | 1 | Inspected / Adjusted | Inspected / Adjusted |
| | 2 | Inspected / Adjusted | Inspected / Adjusted |
| 3 | Inspected / Adjusted | Inspected / Adjusted | |
| Spark Plug 1 | Inspected / Replaced | | |
| Spark Plug 2 | Inspected / Replaced | | |
| Spark Plug 3 | Inspected / Replaced | | |
| Spark Plug Wire 1 | Inspected / Replaced | | |
| Spark Plug Wire 2 | Inspected / Replaced | | |
| Spark Plug Wire 3 | Inspected / Replaced | | |
| Ignition Coil 1 | Inspected / Replaced | | |
| Ignition Coil 2 | Inspected / Replaced | | |
| Ignition Coil 3 | Inspected / Replaced | | |
| Cylinder 1 Compression: | Refer to Table 8 | | |
| Cylinder 2 Compression: | Refer to Table 8 | | |
| Cylinder 3 Compression: | Refer to Table 8 | | |
| Notes: | | | |